

MorphStick

QUICK START



Important tips:

- Device requires 5V DC power through USB-A connector or POE (option)
- To get started, download **MS Tools** from download.morphstick.com
- Connect the device to a PC using the vertical USB-A socket and run **MS Tools**


Download MS Tools from
download.morphstick.com



Connect the device to a PC
using the vertical
USB-A socket and
run **MS Tools**



To configure the device run
MS Tools and press the button,
then follow the instructions



MS Tools is an auxiliary application assisting in configuring and testing the device. Once the device is configured, it can run stand-alone.

For more information, resources,
application notes and videos, visit
www.morphstick.com



The MorphStick family includes a wide variety of data conversion devices, supporting HID keyboard and barcode scanners, RS-232 serial bus, multi-channel loggers, pressure, temperature, humidity and more. Options include Power-over-Ethernet, embedded flash storage, RTC time-stamping and more.

